



# How to DIY Bathroom Shelving Checklist



Original Post: [How to DIY Bathroom Shelving for Under \\$45](#)

## 1. Purchase Your Materials

- Necessary
  - 2"x12" Piece of Wood
  - Minwax Stain (Jacobean)
  - Miniwax Polyurethane
  - Foam Brushes
  - L Shelf Brackets
- Optional
  - Sand Paper (just to clean up the wood a bit if there are rough edges)
  - Clean, Dry Cloth (used to wipe excess stain from wood)
  - Painter's Pyramid Stands (well worth the small cost)
  - Gloves (optional to protect your hands when staining)
  - Rustoleum Spray Paint (optional if you choose to spray paint your own)
  - HomeRight Spray Shelter (only if you end up buying metal L brackets from the hardware store and spray painting them)
  - Circular Saw (only needed if you buy your wood from a place that doesn't cut it for you - Home Depot cut mine to size in store)
  - Multipurpose Laser Level
- See post for affiliate links to purchase any of my recommended items above

## 2. Cut wood to size, if needed

## 3. Lightly sand the wood

## 4. Stain all sides of the wood shelves

## 5. Spray brackets, if needed

## 6. Apply clear coat to the wood shelves

## 7. Attach brackets to shelf

## 8. Hang shelves

